



- NOTES:
1. LHR SHOWN; RHR OPPOSITE.
 2. DIMENSIONS SHOWN IN INCHES AND (mm).
 3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.

RESPONSIBILITY
 Door and Frame Manufacturers are responsible for providing adequate construction or reinforcement for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced door and frames regardless of the type, material or method of construction.

TEMPLATE
 WOOD DOOR
 08, 09 & 14
 BN/DN/DNT/DNU/MN
 NARROW LEVER TRIM
 BP-2 MOUNTING PLATE

HDG. _____ DR. _____	
DETEx CORPORATION	
DO NOT SCALE DRAWING	
DATE 11/16/07	TEMPLATE NUMBER T1038