



NOTES:

1. LHR SHOWN; RHR OPPOSITE.
2. DIMENSIONS SHOWN IN INCHES AND (mm).
3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.

**RESPONSIBILITY**  
 Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction.

**TEMPLATE WOOD DOOR**  
 01D/01DV/02D/02DT/02DU/02DV  
 WIDE LEVER TRIM BP-1/BP-11  
 MOUNTING PLATE

HDG. \_\_\_\_\_ DR. \_\_\_\_\_



DO NOT SCALE DRAWING

DATE 06/16/11

TEMPLATE NUMBER T1152