



- NOTES:
1. LHR SHOWN; RHR OPPOSITE.
 2. DIMENSIONS SHOWN IN INCHES AND (mm).
 3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.
 4. SEE T2002 FOR DEVICE SIDE PREP.

RESPONSIBILITY Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction.		TEMPLATE WOOD DOOR 08, 09 & 14 EU x DM/DMT/DMU WIDE LEVER TRIM-ELECT. LOCKING BP-9 MOUNTING PLATE		HDG. _____ DR. _____	
				DO NOT SCALE DRAWING	
				DATE 7-23-10	TEMPLATE NUMBER T1169