



NOTES:

1. LHR SHOWN; RHR OPPOSITE.
2. DIMENSIONS SHOWN IN INCHES AND (mm).
3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.

RESPONSIBILITY
 Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction.

TEMPLATE
 WOOD DOOR
 08D/08DT/08DU
 09D/09DT/09DU
 14D/14DT/14DU
 WIDE LEVER TRIM
 BP-5 MOUNTING PLATE

HDG. _____ DR. _____	
DETEX CORPORATION	
DO NOT SCALE DRAWING	
DATE 11/16/07	TEMPLATE NUMBER T1055