



NOTES:

1. LHR SHOWN; RHR OPPOSITE.
2. DIMENSIONS SHOWN IN INCHES AND (mm).
3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.

HDG. \_\_\_\_\_ DR. \_\_\_\_\_

**RESPONSIBILITY**  
 Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction.

TEMPLATE  
 WOOD DOOR  
 O3WM  
 CYLINDER ESCUTCHEON TRIM  
 BP-9 MOUNTING PLATE

**DETEX**

DO NOT SCALE DRAWING

DATE 7-23-10	TEMPLATE NUMBER T1164
--------------	-----------------------