



- NOTES:
1. LHR SHOWN; RHR OPPOSITE.
 2. DIMENSIONS SHOWN IN INCHES AND (mm).
 3. REF. DEVICE TEMPLATE FOR "X-X" CENTERLINE.

RESPONSIBILITY Door and Frame Manufacturers are responsible for providing adequate construction or reinforcements for proper installation of hardware shown. All architectural builders hardware must be installed on properly reinforced doors and frames regardless of the type, material or method of construction.		TEMPLATE WOOD DOOR 08, 09 & 14 EU x D/DT/DU/DV WIDE LEVER TRIM-ELECT. LOCKING BP-1/BP-11 MOUNTING PLATE		HDG. _____ DR. _____	
				DO NOT SCALE DRAWING	
				DATE 06/16/11	TEMPLATE NUMBER T1167